

WG1004 **Wall Cladding & Protection**

Application method:

WG1004 general description, technical drawing scheme and the application form of the dilatation profile produced by Arfen are as follows.



1.STEP :

Wall surfaces should be cleaned.

2.STEP :

Apply the adhesives on the wall protection products.

3.STEP:

Measure the height of the line that according to your details.

4.STEP:

Place the products on the surface.

5.STEP:

It will be connected very well.

"ARFEN does supply adhesives."

www.arfen.com

TURKEY Head Office and Factory

Hadimkoy- Istanbul +90 212 485 16 15

For technical support contact us through info@arfen.com or +90 212 485 1615



ARFEN[®]

Çözüm Üretir...